


INSTALLATION INSTRUCTIONS



Center Video-Conferencing Shelf

DISCLAIMER

Milestone AV Technologies and its affiliated corporations and subsidiaries (collectively "Milestone"), intend to make this manual accurate and complete. However, Milestone makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Milestone makes no representation of warranty, expressed or implied, regarding the information contained herein. Milestone assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.

Chief® is a registered trademark of Milestone AV Technologies. All rights reserved.

! IMPORTANT SAFETY INSTRUCTIONS!

! WARNING: A WARNING alerts you to the possibility of serious injury or death if you do not follow the instructions.

! CAUTION: A CAUTION alerts you to the possibility of damage or destruction of equipment if you do not follow the corresponding instructions.

! WARNING: Failure to read, thoroughly understand, and follow all instructions can result in serious personal injury, damage to equipment, or voiding of factory warranty! It is the installer's responsibility to make sure all components are properly assembled and installed using the instructions provided.

! WARNING: Failure to provide adequate structural strength for this component can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the structure to which this component is attached can support five times the combined weight of all equipment. Reinforce the structure as required before installing the component.



! WARNING: Exceeding the weight capacity can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the combined weight of all components located on the FVS300/FVS350 does not exceed 10 lbs (4.5 kg).

! WARNING: RISK OF INJURY TO PERSONS! Do not use this mounting system to support video equipment such as televisions or computer monitors.



! WARNING: Do not use this product outdoors.

--SAVE THESE INSTRUCTIONS--


LEGEND

	Tighten Fastener
	Apretar elemento de fijación
	Befestigungsteil festziehen
	Apertar fixador
	Serrare il fissaggio
	Bevestiging vastdraaien
	Serrez les fixations
	Loosen Fastener
	Aflojar elemento de fijación
	Befestigungsteil lösen
	Desapertar fixador
	Allentare il fissaggio
	Bevestiging losdraaien
	Desserrez les fixations
	Pencil Mark
	Marcar con lápiz
	Stiftmarkierung
	Marcar com lápis
	Segno a matita
	Potloodmerkteken
Marquage au crayon	
	Security Wrench
	Llave de seguridad
	Sicherheitsschlüssel
	Chave de segurança
	Chiave di sicurezza
	Veiligheidssleutel
	Clé de sécurité


DIMENSIONS



TOOLS REQUIRED FOR INSTALLATION



PARTS



Assembly and Installation

IMPORTANT ! : The use of the FVS300 and FVS350 also requires the accessory FCK008 or FCK016.

Assembling Shelf

1. Place shelf (A or B) onto shelf mounting bracket (C). (See Figure 1)




Figure 1

2. Secure shelf using one 10-24 x 5/8" Phillips pan head screw (K). (See Figure 2)

OPTIONAL: The 10-24 x 5/8" button head security screw (H) may be used instead to prevent removal of shelf.




Figure 2

Attaching to Wall

1. Attach mount connector union (F) to the FCK accessory.
2. Attach mount connector (D or E) to the mount connector union (F) for both the top and bottom rail. (See Figure 3)




Figure 3

3. Attach wall mounts to wall following installation instructions included with the wall mounts.
4. Hang shelf unit on rails.
5. Adjust location of shelf and install one 10-24 x 1" Phillips pan head screw (L) to tighten shelf against rails. (See Figure 4)

OPTIONAL: The 10-24 x 1" button head security screw (J) may be used instead to prevent removal of shelf.

6. Hang displays on wall mounts following installation instructions included with the wall mounts.
7. Slide displays to the sides of the shelf.




Figure 4

Camera Installation



WARNING: Exceeding the weight capacity can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the combined weight of all components located on the FVS300/FVS350 does not exceed 10 lbs (4.5 kg).

NOTE: Mounting options will vary depending on the type of camera being mounted.

1. Install 1/4-20 x 3/8" Phillips pan machine screw (M) through mounting slot and into hole on bottom of camera. (See Figure 5)

NOTE: Camera can also be secured to mount by threading tie through outside slots on camera mount and around the camera.

NOTE: It is also acceptable to mount the camera directly to the shelf without any screws or ties.




Figure 5



Our Mounts. **Your Vision.**

Chief Manufacturing, a products division
of Milestone AV Technologies

8807-000077 Rev01
©2012 Milestone AV Technologies, a
Duchossois Group Company
www.chiefmfg.com
07/12

USA/International	A 6436 City West Parkway, Eden Prairie, MN 55344
	P 800.582.6480 / 952.225.6000
	F 877.894.6918 / 952.894.6918
Europe	A Franklinstraat 14, 6003 DK Weert, Netherlands
	P +31 (0) 495 580 852
	F +31 (0) 495 580 845
Asia Pacific	A Office No. 1 on 12/F, Shatin Galleria 18-24 Shan Mei Street Fotan, Shatin, Hong Kong
	P 852 2145 4099
	F 852 2145 4477

