
INSTALLATION INSTRUCTIONS



Sliding Storage Panel



CSSLP15X10

DISCLAIMER

Legrand | AV and its affiliated corporations and subsidiaries (collectively "Legrand | AV"), intend to make this manual accurate and complete. However, Legrand | AV makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Legrand | AV makes no representation of warranty, expressed or implied, regarding the information contained herein. Legrand | AV assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.

DEFINITIONS

MOUNTING SYSTEM: A MOUNTING SYSTEM is the primary Chief product to which an accessory and/or component is attached.

ACCESSORY: AN ACCESSORY is the secondary Chief product which is attached to a primary Chief product, and may have a component attached or setting on it.

COMPONENT: A COMPONENT is an audiovisual item designed to be attached or resting on an accessory or mounting system such as a video camera, CPU, screen, display, projector, etc.

WARNING: A WARNING alerts you to the possibility of serious injury or death if you do not follow the instructions.



CAUTION: A CAUTION alerts you to the possibility of

damage or destruction of equipment if you do not follow the corresponding instructions.



IMPORTANT SAFETY INSTRUCTIONS

WARNING: Failure to read, thoroughly understand, and follow all instructions can result in serious personal injury, damage to equipment, or voiding of factory warranty! It is the installer's responsibility to make sure all accessories are properly assembled and installed using the instructions provided.

WARNING: Exceeding the weight capacity can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the combined weight of all components attached to accessory does not exceed 15 lbs (6.8 kg).


WARNING: Use this accessory only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.

 $oldsymbol{\Lambda}$

WARNING: Never operate this accessory if it is damaged. Return the accessory to a service center for examination and repair.

WARNING: Do not use this accessory outdoors.

--SAVE THESE INSTRUCTIONS--




Installation Instructions CSSLP15X10


LEGEND

	Tighten Fastener	Pencil Mark
G	Apretar elemento de fijación	Marcar con lápiz
	Befestigungsteil festziehen	Stiftmarkierung
	Apertar fixador	Marcar com lápis
	Serrare il fissaggio	Segno a matita
	Bevestiging vastdraaien	Potloodmerkteken
	Serrez les fixations	Marquage au crayon
	Loosen Fastener	Drill Hole
\bigodot	Aflojar elemento de fijación	Perforar
	Befestigungsteil lösen	Bohrloch
	Desapertar fixador	Fazer furo
	Allentare il fissaggio	Praticare un foro
	Bevestiging losdraaien	Gat boren
	Desserrez les fixations	Percez un trou
(4)	Phillips Screwdriver	Adjust
	Destornillador Phillips Kreuzschlitzschraubendreher	Ajustar
		Einstellen
	Chave de fendas Phillips Cacciavite a stella	Ajustar
		Regolare
	Kruiskopschroevendraaier	Afstellen
	Tournevis à pointe cruciforme	Ajuster
O O	Open-Ended Wrench	Remove
	Llave de boca	Quitar
	Gabelschlüssel	Entfernen
	Chave de bocas	Remover
	Chiave a punte aperte	Rimuovere
	Steeksleutel	Verwijderen
	Clé à fourche	Retirez
	By Hand	Optional
	A mano	Opcional
	Von Hand	Optional
	Com a mão	Opcional
	A mano	Opzionale
	Met de hand	Optie
	À la main	En option
	Hex-Head Wrench	Security Wrench
	Llave de cabeza hexagonal	Llave de seguridad
	Sechskantschlüssel	Sicherheitsschlüssel
	Chave de cabeça sextavada	Chave de segurança
	Chiave esagonale	Chiave di sicurezza
	Zeskantsleutel	Veiligheidssleutel
		1.59.10.000.000

TOOLS REQUIRED FOR INSTALLATION



PARTS



Installation Instructions CSSLP15X10

INSTALLATION

NOTE: The storage panel (G) may be installed using either of two methods. Proceed to either **Installing Storage Panel to Wall** section <u>OR</u> **Installing Storage Panel to Extrusion** section.

Installing Storage Panel to Wall

NOTE: The storage panel (G) may be installed directly on the wall in one of two horizontal positions or vertically below the display. (See Figure 1) or (See Figure 2)




Figure 1




Figure 2

- 1. Determine location for the CSSLP15X10.
- 2. Using the CSSLP15X10 (G) as a template, mark the locations of four mounting holes. (See Figure 3)




Figure 3

3. Drill four 1/4" pilot holes and insert drywall anchors (A) at markings. (See Figure 3)



CAUTION: The storage panel must be mounted with the clip at the bottom. (See Figure 1)

 Fasten storage panel (G) to wall using four #10 x 1" Phillips pan wood screws (B). (See Figure 3)

Installing Storage Panel to Extrusion

NOTE: The storage panel may be located anywhere along the extrusion. For ease of use, it may be more convenient to place it to the extreme left or right side of the extrusion.

1. Remove screws and end cap from extrusion. (See Figure 4)




Figure 4

 Insert four 5/16-18 x 3/8" button head cap screws (D) into the two slot nuts (C) and partially tighten. (See Figure 5) 3. Slide two slot nuts (C) into end of extrusion. (See Figure 5)




Figure 5



CAUTION: The storage panel must be mounted with the clip at the bottom. (See Figure 1) and (See Figure 6)

Hold the storage panel (G) over the four button head screws
 (D) and lower the storage panel keyholes over the screws.
 (See Figure 6)




Figure 6

Tighten screws securely against the storage panel.

Installation Instructions CSSLP15X10

Attaching Components

- Remove mounting plate from storage panel by pressing inward on the clip located at the bottom of the storage panel. (See Figure 7)
- Place component(s) on mounting plate and position in the desired location with the hole pattern in mounting plate best aligned to component mounting holes. (See Figure 7)




Figure 7

- 3. Using the fasteners provided with the component and the washers (E), attach the component to the mounting plate. (See Figure 7)
- 4. Return mounting plate to storage panel by installing the side without the clip into the panel first, followed by the side with the clip until it clicks into place. (See Figure 8)
- OPTIONAL: If desired, install plastic rivet (F) into hole next to clip to secure the mounting plate in place.(See Figure 8)




Figure 8

Component Panel Usage

 Gently push component panel in until it unlocks. (See Figure 9)




Figure 9

Pull component panel out away from display. (See Figure 10)




Figure 10

- 3. Access components on panel as desired.
- Push component panel back into place until it "clicks" back into its original position. (See Figure 10)



A brand of Lilegrand

8800-003297 Rev00 ©2021 Legrand | AV www.legrandav.com 04/2021 **USA/International** A 6436 City West Parkway, Eden Prairie, MN 55344

Europe

P 800.582.6480 / 952.225.6000

F 877.894.6918 / 952.894.6918

A Franklinstraat 14, 6003 DK Weert, Netherlands

P +31 (0) 495 580 852

F +31 (0) 495 580 845

Asia Pacific A Office No. 918 on 9/F, Shatin Galleria

18-24 Shan Mei Street

Fotan, Shatin, Hong Kong

P 852 2145 4099

F 852 2145 4477

