

INSTALLATION INSTRUCTIONS





Fusion Modular Ceiling Heads



FMSCM / FMSCA

FMSCM / FMSCA Installation Instructions

DISCLAIMER

Milestone AV Technologies and its affiliated corporations and subsidiaries (collectively "Milestone"), intend to make this manual accurate and complete. However, Milestone makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Milestone makes no representation of warranty, expressed or implied, regarding the information contained herein. Milestone assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.

Chief® is a registered trademark of Milestone AV Technologies. All rights reserved.

DEFINITIONS

MOUNTING SYSTEM: A MOUNTING SYSTEM is the primary Chief product to which an accessory and/or component is attached.

ACCESSORY: AN ACCESSORY is the secondary Chief product which is attached to a primary Chief product, and may have a component attached or setting on it.

COMPONENT: A COMPONENT is an audiovisual item designed to be attached or resting on an accessory or mounting system such as a video camera, CPU, screen, display, projector, etc.

WARNING: A WARNING alerts you to the possibility of serious injury or death if you do not follow the instructions.

CAUTION: A CAUTION alerts you to the possibility of damage or destruction of equipment if you do not follow the corresponding instructions.



IMPORTANT SAFETY INSTRUCTIONS

WARNING: Failure to read, thoroughly understand, and follow all instructions can result in serious personal injury, damage to equipment, or voiding of factory warranty! It is the installer's responsibility to make sure all mounting systems / accessories are properly assembled and installed using the instructions provided.




WARNING: Exceeding the weight capacity can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the combined weight of all components attached to mounting system does not exceed the weight capacity listed in the Fusion Modular Systems installation instructions.


IMPORTANT!: These installation instructions must be used in conjunction with the **Fusion Modular Systems** installation instructions.

--SAVE THESE INSTRUCTIONS--

Installation Instructions FMSCM / FMSCA

DIMENSIONS






LEGEND


	Tighten Fastener	Pencil Mark
G	Apretar elemento de fijación	Marcar con lápiz
	Befestigungsteil festziehen	Stiftmarkierung
	Apertar fixador	Marcar com lápis
	Serrare il fissaggio	Segno a matita
	Bevestiging vastdraaien	Potloodmerkteken
	Serrez les fixations	Marquage au crayon
	Loosen Fastener	Drill Hole
0	Aflojar elemento de fijación	Perforar
	Befestigungsteil lösen	Bohrloch
	Desapertar fixador	Fazer furo
	Allentare il fissaggio	Praticare un foro
	Bevestiging losdraaien	Gat boren
	Desserrez les fixations	Percez un trou
•	Phillips Screwdriver	Adjust
	Destornillador Phillips	Ajustar
	Kreuzschlitzschraubendreher	Einstellen
	Chave de fendas Phillips	Ajustar
	Cacciavite a stella	Regolare
	Kruiskopschroevendraaier	Afstellen
	Tournevis à pointe cruciforme	Ajuster
650	Open-Ended Wrench	Remove
	Llave de boca	Quitar
	Gabelschlüssel	Entfernen
	Chave de bocas	Remover
	Chiave a punte aperte	Rimuovere
	Steeksleutel	Verwijderen
	Clé à fourche	Retirez
	By Hand	Optional
	A mano	Opcional
	Von Hand	Optional
	Com a mão	Opcional
	A mano	Opzionale
	Met de hand	Optie
	À la main	En option
	Hex-Head Wrench	Security Wrench
	Llave de cabeza hexagonal	Llave de seguridad
	Sechskantschlüssel	Sicherheitsschlüssel
	Chave de cabeça sextavada	Chave de segurança
	Chiave esagonale	Chiave di sicurezza
	Zeskantsleutel	Veiligheidssleutel
	Clé à tête hexagonale	Clé de sécurité

Installation Instructions FMSCM / FMSCA

TOOLS REQUIRED FOR INSTALLATION



PARTS



INSTALLATION

NOTE: The following procedure assumes that Chief UL Listed CPA or CMA ceiling plates (not included) and extension columns (not included) have been properly installed following instructions provided with ceiling plates and extension columns.

 The ceiling plates and columns should be installed approximately spaced at center of outside screens, and spacings should not exceed those outlined in the Fusion Modular Systems installation instructions.

IMPORTANT!: The weight of the system should be evenly distributed across ceiling plates.

IMPORTANT!: Also be sure to reference ceiling system attachment guidelines in the **Fusion Modular Systems** installation instructions.

NOTE: Proceed to Attaching Ceiling Head to NPT Column section or Attaching Ceiling Head to CPA Column section, as appropriate.

Attaching Ceiling Head to 1-1/2" NPT Column

- Slide ceiling head (K or L) up from below onto installed column (not included). (See Figure 1)
- 2. Thread bottom coupling (M) onto installed column until tight, with a minimum of four threads engaged. (See Figure 1)
- 3. Install and tighten one 10-24 x 1/4" set screw (J) into bottom coupling (M). (See Figure 1)




Figure 1

 Tighten two 5/16" x 3/4" set screws (E) against column. (See Figure 2)




Figure 2

Attaching Ceiling Head to CPA Column

- Slide ceiling head (K or L) up from below onto installed column (not included). (See Figure 3)
- Line up holes in sides of ceiling head (K or L) with holes in column.




Figure 3

Install two 5/16" x 2" self-tapping screws (A) through two 5/16" lock washers (C), two friction washers (B), sides of ceiling head (K or L), and into installed column. (See Figure 3)

Installation Instructions FMSCM / FMSCA

 Install and tighten two 5/16" set screws (E) against column. (See Figure 4)




Figure 4

Attaching Mounting Rail to Ceiling Head

IMPORTANT!: Use the FMSCM height-adjust ceiling head (K) on the outside of the mounting rails, or FMSCA floating ceiling head (L) at the center of the mounting rails.

NOTE: Attach one end cap to one end of mounting rail following instructions included with the FMSECAP.

Slide the hook plate (N) into mounting rail. (See Figure 5)




Figure 5

- Lift the mounting rail with the hook plate up to the ceiling head (K or L). (See Figure 6)
- Attach hook plate (N) with mounting rail to ceiling head (K or L) using four 5/16 x 1/2" button head cap screws (D). (See Figure 6)




Figure 6

Adjust and Level Mounting Rail via Ceiling Head

- Adjust the height of the ceiling head, as necessary, to level the mounting rail across the columns. (See Figure 7)
 - **Tighten** the ceiling head height-adjust screw on the FMSCM to **raise** the mounting rail.
 - Loosen the ceiling head height-adjust screw on the FMSCM to lower the mounting rail.
- Tighten the adjustment screw at the bottom of the FMSCA ceiling head to hold the FMSCA (center) ceiling head at the same level as the FMSCM (outer) ceiling heads.




Figure 7

- 3. Add back cover (P) to ceiling head (K or L). (See Figure 7)
- Attach remaining end cap to end of mounting rail following instructions included with the FMSECAP.



Chief, a products division of Milestone AV Technologies

8800-002849 Rev00 ©2016 Milestone AV Technologies www.milestone.com 06/16 USA/International A 6436 City West Parkway, Eden Prairie, MN 55344

P 800.582.6480 / 952.225.6000

F 877.894.6918 / 952.894.6918

Europe A Franklinstraat 14, 6003 DK Weert, Netherlands

P +31 (0) 495 580 852

F +31 (0) 495 580 845

Asia Pacific A Office No. 918 on 9/F, Shatin Galleria

18-24 Shan Mei Street

Fotan, Shatin, Hong Kong

P 852 2145 4099

F 852 2145 4477

